

WILBERS FEDERBEINE (WILBERS SHOCK ABSORBER)











AUTOFahrWERKE (CAR SHOCK ABSORBER)










Zubehör										Extras																																																	
Höhenverstellung pro Federbein					629-000-00					€ 99,-					Ride height adjustment per shock absorber					629-000-00					€ 99,-																																		
Hydraulische Federvorspannung für 640/641/642/643 pro Federbein:					625-046-00					€ 199,-					Hydraulic preload adjustment for 640/641/642/643 per shock absorber:					625-046-00					€ 199,-																																		
Hydraulische Federvorspannung für 630/631/632/633 pro Federbein:					625-036-00					€ 199,-					Hydraulic preload adjustment for 630/631/632/633 per shock absorber:					625-036-00					€ 199,-																																		
						€		630 / 640				€		631 / 641				€		632 / 642				P P/S Q Q/S PSD QS/PS		€				Deutsch				English																									
CORVETTE																																																											
Chevrolet					C 4					X					630-803-01					799,-															Vorne					Front																			
Chevrolet					C 4					X					630-803-00					799,-															Hinten					Rear																			
DONKERVOORT																																																											
Car										X					630-731-00					799,-										633-731-00					S					1199,-					Vorne Länge 313 mm					Front length 313 mm									
Car										X					630-731-01					799,-					631-731-01					1199,-															Hinten Länge 423 mm					Rear length 423 mm									
FERRARI																																																											
328 GTB/GTS					ZFFWA20B/F106					87-88					X					640-336-00					479,-															Vorne, links ohne ABS					Front, left, no ABS														
328 GTB/GTS					ZFFWA20B/F106					87-88					X					640-336-01					479,-															Vorne rechts ohne ABS					Front, right, no ABS														
328 GTB/GTS					ZFFWA20B/F106					87-88					X					640-336-09					479,-															Hinten, links ohne ABS					Rear, left, no ABS														
328 GTB/GTS					ZFFWA20B/F106					87-88					X					640-336-10					479,-															Hinten, rechts ohne ABS					Rear, right, no ABS														
328 GTS/GTB										88-89					X					640-770-00					899,-															Vorne mit ABS					Front with ABS														
328 GTS/GTB										88-89					X					640-770-09					899,-															Hinten mit ABS					Rear with ABS														
Ferrari 330 GTC										66>					X					640-804-00					899,-															Vorne					Front														
Ferrari 330 GTC										66>					X					640-804-01					899,-															Hinten					Rear														
F 365										76>					X					640-423-00					899,-															Vorne					Front														
F 365										76>					2 X					630-423-00					1598,-															Hinten (4 Federbeine)					Rear (4 shock absorber)														
512 BB					LM					78>					X					640-782-00					899,-															Vorne					Front														
512 BB					LM					78>					2 X					630-782-00					1598,-															Hinten (4 Federbeine)					Rear (4 shock absorber)														
365 GTB 4										75>					X					640-854-00					899,-															Vorne					Front														
365 GTB 4										75>					X					640-854-01					899,-															Hinten					Rear														
KANTNER																																																											
Auto Cross rear										X															632-267-00					999,-															Hinten					Rear									
KLAUS																																																											
Car															641-476-00					699,-															Vorne					Front																			
Car															641-477-00					699,-															Hinten					Rear																			
LAMBORGHINI																																																											
Gallardo										X					640-250-00					899,-					641-250-00					1299,-															Vorne					Front									
Gallardo										X					640-250-01					899,-					641-250-01					1299,-															Hinten					Rear									
LOTUS ELISE																																																											
I Car										X					630-553-01					799,-					631-553-01					1199,-															I vorne, Standard Länge, mit TÜV					I front, standard length, with TÜV									
I Car										X					630-553-00					799,-					631-553-00					1199,-															I hinten, Standard Länge, mit TÜV					I rear, standard length, with TÜV									
I Car Sport										X					630-553-08					799,-					631-553-08					1199,-															I vorne/ Sport, TL 30 mm					I front/ Sport, 30 mm lower									
I Car Sport										X					630-553-09					799,-					631-553-09					1199,-															I hinten/ Sport, TL 20 mm					I rear/ Sport, 20 mm lower									
II Car					SCCGA					01>					X					630-087-00					799,-					633-087-00					S					1199,-					II vorne					II front									
II Car					SCCGA					01>					X					630-087-01					799,-					631-087-01					1199,-															II hinten					II rear				
II Car Sport					SCCGA					01>					X															633-087-02					S					1199,-					II vorne/ Sport					II front/ Sport									

WILBERS FEDERBEINE (WILBERS SHOCK ABSORBER)





				€		€		€		P P/S Q Q/S PSD QS/PS	€					
												Deutsch		English		
LOTUS																
Super 7		alle	X	630-722-00	799,-								Vorne / hinten	Front / rear		
OPEL ohne TÜV (no TÜV)																
Speedster	WOLDEAR-N	02>	X	630-642-02	799,-	631-642-02	1199,-						Vorne Sport/Race, FW - 40 mm = Std.	Front Sport/Race, chassis -40 mm=standard		
Speedster	WOLDEAR-N	02>	X	630-642-03	799,-	631-642-03	1199,-						Hinten Sport/Race, FW - 30 mm = Std.	Rear Sport/Race, chassis -30 mm=standard		
OPEL mit TÜV (with TÜV)																
Speedster	WOLDEAR-N	02>	TÜV	X	630-642-00	799,-	631-642-00	1199,-					Vorne Straße/Sport, FW - 15 mm = Std.	Front Road/Sport, chassis -15 mm=standard		
Speedster	WOLDEAR-N	02>	TÜV	X	630-642-01	799,-	631-642-01	1199,-					Hinten Straße/Sport, FW - 15 mm = Std.	Rear, Road/Sport, chassis -15 mm=standard		
SUPERFORMANCE																
Seven S1 front			X	630-860-00	799,-				633-860-00	S	1199,-					
Seven S1 rear			X	630-860-01	799,-											
Cobra RC	427 S /C	65-06	X	640-801-00	899,-	641-801-00	1299,-						Vorne	Front		
Cobra RC	427 S /C	65-06	X	640-801-01	899,-			642-801-02	1299,-				Hinten	Rear		
Cobra RC Coupé		67>	X					642-781-00	1299,-				Vorne	Front		
Cobra RC Coupé		67>	X					642-781-01	1299,-				Hinten	Rear		
Ford GT 40			X	640-863-00	899,-	641-863-00	1299,-						Vorne	Front		
Ford GT 40			X	640-863-01	899,-							643-863-01	QS	1698,-	Hinten	Rear
DE TOMASA																
front			X			641-728-00	1299,-									
rear			X			641-728-01	1299,-									
WESTFIELD																
Car		alle	X	630-450-01	799,-	631-450-01	1199,-						Vorne Länge 320 mm	Front length 320 mm		
Car		alle	X	630-450-00	799,-	631-450-01	1199,-						Vorne Länge 355 mm	Front length 355 mm		
Car		alle	X	630-450-05	799,-	631-450-05	1199,-	642-450-05	1299,-				Hinten Länge 320 mm	Rear length 320 mm		
Car		alle	X	630-450-06	799,-	631-450-06	1199,-						Hinten Länge 355 mm	Rear length 355 mm		
Car		alle	X			631-450-02	1199,-						Vorne Länge 355 mm	Front length 355 mm		
Car			X					632-450-00	999,-				Hinten Länge 320 mm	Rear length 320 mm		
ZAUBER																
TVR Auto			X	640-552-00	1798,-								Satz = 4 Stück	1 set = 4 pieces		

TRIKE

					€		€		€		€			
												Deutsch		English
RF 1		03>		640-727-00									Vorne	Front
RF 1		03>	X			641-727-01	1299,-						Hinten	Rear

Hilfsfeder für Autofahrwerke (Auxiliary springs for car suspension)

		€
Eibach ERS-40-60-20 inkl. Federteller/incl. spring cup	702-001-00	49,-